


CYLINDER, CYLINDER HEAD



Ref. No.	Part No.	Part Name	Quantity	Remarks
1	316B0800	NUT, 8m/m	12	
2	460E0800	WASHER-plain, 8m/m	12	
3	92070-011-A	SPARK PLUG, B-9HC	1	
4	11001-053	CYLINDER HEAD, L.H. & R.H.	2	
	11001-053-80	CYLINDER HEAD, Buff Finish L.H. & R.H.	2	S2-A
5	11001-054	CYLINDER HEAD, CENTER	1	
6	11004-043	GASKET-cylinder head	3	
7	11005-068	CYLINDER, L.H.	1	
8	11005-069	CYLINDER, CENTER	1	
9	11005-070	CYLINDER, R.H.	1	
10	11009-027	GASKET-cylinder base	3	
11	172G0820	STUD, 8x20	6	
12	15062-014	GASKET-air inlet	6	
13	15061-012	INSULATOR-heat	3	
14	15060-012	INLET PIPE	3	
15	461F0800	WASHER-spring, 8m/m	6	
16	316B0800	NUT, 8m/m	6	
17	172G0830	STUD, 8x30	6	
18	18067-003	GASKET-exhaust pipe	3	

CONTENTS

AIR CLEANER	B7
BRAKE, DISC	E5
BRAKE DISC, EQUIPMENT	C7
CABLES	F4
CARBURETOR	C2
CLUTCH	A7
COVERS, ENGINE	B5
COVERS, SIDE	E7
CRANKCASE	A5
CRANKSHAFT	A6
CYLINDER, CYLINDER HEAD	A4
ELECTRICAL, ENGINE	B6
ELECTRICAL, WIRING	G3
FENDERS	D7
FOOTREST	G6
FORK, FRONT, S2	D4
FORK, FRONT, S2-A	D5, D6
FRAME	C4
GEAR CHANGE MECHANISM	B3
HANDLEBAR	D2, D3
HEADLAMP, METERS, S2	F5
HEADLAMP, METERS, S2-A	F6
HUB, FRONT, S2	E4
HUB, FRONT, S2-A	E5
HUB, REAR	E3
KICKSTARTER	B4
MUFFLER	B7
OIL PUMP	C3
OPTIONAL PARTS	G4
PISTON, RINGS	A6
SEAT, DUAL, S2	F2
SEAT, DUAL, S2-A	F3
SWINGARM	C5
TAIL LAMP, S2	F7
TAIL LAMP, S2-A	G2
TANK, FUEL	E6
TANK, OIL	E7
TOOLS	G4
TRANSMISSION	B2
TURN SIGNAL, S2	F7
TURN SIGNAL, S2-A	G2
WHEELS	E2