


DISC BRAKE EQUIPMENT

CONTENTS



Ref. No.	Part No.	Part Name	Quantity	Remarks
1	43015-001	CYLINDER ASSY—master	1	
1	43026-001	CAP—oil cup	1	
2	43027-001	PLATE—diaphragm	1	
3	43028-001	DIAPHRAGM	1	
4	43073-001	REPAIR SET—master cylinder	1	
4	43017-001	VALVE ASSY—check	1	
5	43018-001	SPRING ASSY—return	1	
6	43019-001	CUP—primary	1	
7	43072-001	PISTON ASSY	1	
8	43022-001	STOPPER	1	
9	8111800	CIRCLIP, 18 m/m	1	
10	43024-001	DUST COVER	1	
11	43025-001	STOPPER—dust cover	1	
12	43016-001	CYLINDER—master	1	
13	43029-001	LEVER—front brake	1	
14	43080-002	BOLT—lever adjust	1	
15	43031-001	WASHER—lock	1	
16	312N0600	NUT, 6 m/m	1	
17	313N0800	NUT, 8 m/m	1	
18	43043-001	BOLT—handle lever pivot	1	
19	43034-001	HOLDER—master cylinder	1	
20	110N0625	BOLT—hex head, 6 x 25	2	
21	110B0600	WASHER—plain, 6 m/m	2	
22	43066-001	BOLT—oil	3	
23	43067-001	WASHER—oil bolt	6	
24	43059-006	HOSE—master cylinder brake	1	
25	43069-002	DUST COVER	1	
26	43064-001	DAMPER—RUBBER—brake hose	1	I.D.=13.5φ
27	43065-001	SWITCH ASSY—front brake	1	
28	92073-022	RUBBER CAP—front brake switch	1	
29	43059-008	HOSE—calliper brake	1	
30	43060-003	PIPE—bridge	1	
31	43064-005	DAMPER—RUBBER—brake hose	1	I.D.=15φ
32	43074-001	TUBE	1	

AIR CLEANER	B7
BRAKE, DISC	E5
BRAKE DISC, EQUIPMENT	C7
CABLES	F4
CARBURETOR	C2
CLUTCH	A7
COVERS, ENGINE	B5
COVERS, SIDE	E7
CRANKCASE	A5
CRANKSHAFT	A6
CYLINDER, CYLINDER HEAD	A4
ELECTRICAL, ENGINE	B6
ELECTRICAL, WIRING	G3
FENDERS	D7
FOOTREST	C6
FORK, FRONT, S2	D4
FORK, FRONT, S2-A	D5, D6
FRAME	C4
GEAR CHANGE MECHANISM	B3
HANDLEBAR	D2, D3
HEADLAMP, METERS, S2	F5
HEADLAMP, METERS, S2-A	F6
HUB, FRONT, S2	E4
HUB, FRONT, S2-A	E5
HUB, REAR	E3
KICKSTARTER	B4
MUFFLER	B7
OIL PUMP	C3
OPTIONAL PARTS	G4
PISTON, RINGS	A6
SEAT, DUAL, S2	F2
SEAT, DUAL, S2-A	F3
SWINGARM	C5
TAIL LAMP, S2	F7
TAIL LAMP, S2-A	G2
TANK, FUEL	E6
TANK, OIL	E7
TOOLS	G4
TRANSMISSION	B2
TURN SIGNAL, S2	F7
TURN SIGNAL, S2-A	G2
WHEELS	E2

S2-A

C7