


H1-E Wiring Diagram (US Model)



Ignition Switch Internal Connection

Lead	Ignition	Ground	H. L.	Tail	Battery	Coil
Color	Bk/W	Bk/Y	Bl	R/W	W	Br
OFF	•	•	•	•	•	•
ON	•	•	•	•	•	•
PARK	•	•	•	•	•	•

(136-3)