


H2-B Wiring Diagram (European Model)



*France
12V 36/36W
Germany
12V 35/35W

Ignition Switch Internal Connection

Lead	Ignition	Ground	H.L.	Tail	Battery	Coil
Color	Bk/W	Bk/Y	Bl	R/W	W	Br
OFF	●	●	●	●	●	●
ON	●	●	●	●	●	●
PARK	●	●	●	●	●	●

(156-1)