

- Float mechanism 47-48, 51, 52
- Foot rests 98
- Fork, front 83-91
- Frame 53
- Friction plates 27-31
- Fuel tank 95-97
- Fuel tap 95-98

- Gap, spark plug 107, 118
- Gasoline tank 95-97
- Gasoline tap 95-98
- Gear, primary 31-32
- Gear shift mechanism 32-34, 39, 41
- Generator
 - AC 22-23, 101, 103, 120
 - Signal 23, 108-110, 115-118, 120

- Handlebars 81-83
- Head, cylinder 15-18
- Honing 17, 18
- Hubs 61-67, 69

- Idle adjustment 9-11
- Ignition
 - HI CDI 108-112
 - Contact breaker 105-107
 - Magneto CDI 113, 115-119
- Injectolube 43-46

- Jet
 - Main 48, 50-52
 - Needle 49, 50-52
 - Pilot 49, 50-52
- Jet needle 48-49, 50-52

- Kick stand 98
- Kick starter 24-26, 42-43

- Length, spring
 - Brake shoe 65
 - Clutch 30
 - Front fork 89
 - Master cylinder 79
- Level, float chamber fuel 47-48, 51, 52
- Lining thickness, brake 65
- Lubrication 43-46

- Needle, jet 48-49, 50-52
- Needle jet 49, 50-52

- Main jet 48, 50-52
- Mufflers 99-100

- Oil, front fork 89
- Oil pump 11-12, 24, 26, 43-46
- Oil tank 95-97
- Overheating 15, 80, 124
- Oversize pistons 18

- Performance curves 3-4

- Pin, piston 18-20
- Pinion gears 24
- Piston 18-20
- Piston pin 18-20
- Piston rings 18, 19, 20-22
- Pivot shaft
 - Nut torque 56
 - Runout 55
- Plates, clutch 27-31
- Play, connecting rod small end 20
- Plug torque
 - Spark plug 18
 - Oil drain plug 27
- Plug, spark 1, 18, 107, 118
- Port, cylinder
 - Measurements 15
 - Timing 15
- Pressure, tire air 57
- Primary gear 31-32
- Pump, oil 11-12, 24, 26, 43-46

- Rectifier 101-104, 113-114, 120
- Regulator 103-105, 113-114, 120
- Rim, tire 57, 60
- Rings, piston 18, 19, 20-22
- Runout
 - Axle 60
 - Crankshaft 38
 - Disc 80
 - Pivot shaft 55
 - Rim 60

- Schematic diagrams 131-137
- Seat 99
- Seizure, piston 19
- Selector fork clearance 41
- Semiconductors 102-103
- Shift mechanism 12, 32-34, 39, 41
- Shock absorbers
 - Front 83-91
 - Rear 91-93
- Signal generator 23, 108-110, 115-118, 120
- Small end, connecting rod 20
- Spark plugs 1, 18, 107, 118
- Specifications 1-2
- Spoke size 57
- Spring length
 - Brake shoe 65
 - Clutch 30
 - Front fork 89
 - Master cylinder 79
- Sprocket
 - Engine 22, 23, 24
 - Rear 62, 65, 66
- Stands 98
- Starter, kick 24-26, 41-43
- Steering damper 85, 93
- Steering stem 83-91
- Swing arm 54-56
- Switch, brake lamp 67, 68, 74, 78